
























MAXINK INK REFILL KITS SERIES FOR EPSON CARTRIDGE REFILL MODEL

| MODEL | COLOR | FOR USE ON | FOR USE ON |
|--------------|---|--|--|
| MI-0101A-BX1 |  | T013 T003 T017 T019 T007 T010 T015 T026 T028 T036 T038 T040 T0321 T0331 T0341 T0461 T0441 T0431 T0481 T0491 T0548 S020025 S020039 S020034 S020047 S020093 S020187 S020108 S020189 S020138 | EPSON Stylus Color 200/300/400/440/460/480/480SX/480SXU/ 500/580/600/640/660/670/680/680T/685/740/740V/760/777/777V/ 800/800C/850/850C/850N/850Ne/860/880/8 ⁹ /900/900G/900N/ 980/980N/1520/1160/1115/PRO/PRO XL/PRO XL+ EPSON Stylus Photo EX/EX2/EX3/700/710/720/750/780/ 785EPX/790/810/820/825/830/870/875DC/890/895/900/915/ 925/935/950/960/1200/1270/1280/1290/1290S/2000P/2100/ 2200/R200/R210/R300/R300M/R310/R800/RX500/RX510/ RX600/R320/RX630 EPSON Stylus 400/800/800+/1000/C20/C20SX/C40/C40S/C40UX/ C41/C41SX/C41UX/C42+/C42UX/C43UX/C43SX/C44UX/C45/C46/ C50/C60/C61/C62/C70/C80/C80N/C80WN/C82/C82N/C82WN/ CX3100/CX3200/CX5100/CX5200/CX5300/CX5400/C63/C64/C65/ C66/C83/C84/C86/CX4600/CX6300/CX6400/CX6500/CX6600/ CX3600/CX3650/CX1500/CX3500 EPSON Stylus Scan 2000/2500/2500 PRO EPSON MJ 520C/810C/830C/830CS/930C/3000CU/6000C EPSON PM 680C/700C/730C/750C/760C/770C/800C/850PT/880C/ 950C/2000C/2200C/3000C/3300C/3500C EPSON IP 100 EPSON MC 2000 EPSON 1000ICS LENOVO C.J100 |
| MI-0102A-BX1 |  | T001 T029 T014 T005 T018 T020 T037 T039 T041 T008 T009 T016 T027 T0322 T0323 T0324 T0332 T0333 T0334 | EPSON Stylus Color 300/400/440/460/480/480SX/480SXU/580/ 600/640/660/670/680/680T/685/740/740V/760/777/777V/800/850/ 850N/850Ne/860/8 ⁹ /880/900/900G/900N/980/980N/1160/1520 EPSON Stylus Photo EX/EX2/EX3/700/710/720/750/780/785EPX/ 790/810/820/825/830/870/875DC/875DCS/890/895/900/915/925/ 935/950/960/1200/2100/2200/1270/1280/1290/1290S/2000P/R200/ R210/R300/R300M/R310/R800/RX500/RX510/RX600/RX630 EPSON Stylus C20/C20SX/C40/C40S/C40UX/C41/C41SX/C41UX/ C42+/C42UX/C43UX/C43SX/C44UX/C50/C60/C61/C62/C70/C80/ C80N/C80WN/C82/C82N/C82WN/CX3100/CX3200/CX5100/ CX5200/CX5300/CX5400/C45/C46/C63/C64/C65/C66/C83/C84/ C86/CX4600/CX6300/CX6400/CX6500/CX6600/CX3600/ CX3650/CX1500/CX3500 |
| MI-0103A-BX1 |  | T0342 T0343 T0344 T0422 T0423 T0424 T0472 T0473 T0474 | EPSON MJ 520C/830C/830CS/930C/6000C EPSON PM 600C/670C/680C/700C/730C/750C/760C/770C/800C/ 850PT/880C/950C/2000C/2200C/3000C/3300C/3500C EPSON Stylus Scan 2000/2500/2500 PRO EPSON IP 100 EPSON MC 2000 EPSON 600Q/1000ICS LENOVO C.J100 |
| MI-0104A-BX1 |  | T0442 T0443 T0444 T0452 T0453 T0454 T0482 T0483 T0484 T0492 T0493 T0494 T0542 T0543 T0544 S020138 S020089 S020191 S020110 S020193 | EPSON Stylus Photo EX/EX2/EX3/700/710/720/750/780/ 785EPX/790/810/820/825/830/870/875DC/875DCS/890/ 895/900/915/925/935/950/960/1200/1270/1280/1290/1290S/ 2000P/2100/2200/R200/R210/R300/R300M/R310/RX500/ RX510/RX600/RX630 EPSON PM 600C/670C/680C/700C/730C/750C/760C/ 770C/800C/850PT/880C/950C/2000C/2200C/3000C/ 3300C/3500C/4000PX EPSON IP 100 EPSON MC 2000 |
| MI-0105A-BX1 |  | T001 T008 T009 T016 T027 T0335 T0336 T0345 T0346 | EPSON Stylus Photo EX/EX2/EX3/700/710/720/750/780/ 785EPX/790/810/820/825/830/870/875DC/875DCS/890/ 895/900/915/925/935/950/960/1200/1270/1280/1290/1290S/ 2000P/2100/2200/R200/R210/R300/R300M/R310/RX500/ RX510/RX600/RX630 EPSON PM 600C/670C/680C/700C/730C/750C/760C/ 770C/800C/850PT/880C/950C/2000C/2200C/3000C/ 3300C/3500C/4000PX EPSON IP 100 EPSON MC 2000 |
| MI-0106A-BX1 |  | T0485 T0486 T0495 T0496 S020110 S020193 | EPSON Stylus Photo EX/EX2/EX3/700/710/720/750/780/ 785EPX/790/810/820/825/830/870/875DC/875DCS/890/ 895/900/915/925/935/950/960/1200/1270/1280/1290/1290S/ 2000P/2100/2200/R200/R210/R300/R300M/R310/RX500/ RX510/RX600/RX630 EPSON PM 600C/670C/680C/700C/730C/750C/760C/ 770C/800C/850PT/880C/950C/2000C/2200C/3000C/ 3300C/3500C/4000PX EPSON IP 100 EPSON MC 2000 |

MAXINK INK REFILL KITS SERIES FOR CANON CARTRIDGE REFILL MODEL

| MODEL | COLOR | FOR USE ON | FOR USE ON |
|--------------|---|--|--|
| MI-1101A-BX1 |  | BC-01 BC-02 BX-2 BC-03 BX-3 BCI-10BK BCI-11BK BC-20 BCI-21BK BCI-24BK BCI-3eBK | CANON BJ-5/10/20/30/30V/100/200/300 CANON BJC-35/50/50G/55/70/80/85/85W/210/240/250/251/ 255/255SP/265SP/300J/1000/1000SP/1010/3000/3010/3100/ 4000/4100/4200/4200SP/4300/4310SP/4550/4650/5000/5500/ 8000/8100/8200/8500 CANON BJ F300/F600 CANON BJ S200/S330/S200x/S300/S400/S400SP/S450/S500/ S520S/S530/S530D/S600/S630/S750/S4500/S6300 CANON i250/i255/i350/i355/i320/i450/i455/i470D/i475D/i550/ i560/i850/i860/i865/i6100/i6500 CANON FAX B100/B110/B200/B220/B310/B320/B320F/B340/ B340F/B360/B400/B120/B140/B820/B840/B822 CANON Multipass 10/MP360/MP370/MP390/MP700/MP730/F20 CANON StarWriter 60/70/80/85/95 CANON PIXMA iP3000/iP4000/iP5000/iP1000/iP1500/iP2000 |
| MI-1102A-BX1 |  | BCI-21C | CANON BJC-35/50/50G/55/70/80/85/85W/210/240/250/251/ 255/265SP/400/400J/1000/1000SP/1010/2000SP/2100SP/4000/ 4100/4200/4200SP/4300/4310SP/4550/4650/4650SP/5000/ 5500/5500J |
| MI-1103A-BX1 |  | BCI-24C BCI-11C | CANON BJ F100 CANON S100SP/S200/S200x/S300/S330 CANON MultiPASS B-10/C20/C30/C50/C70/C2500/MP360/ MP370/MP390/F20 |
| MI-1104A-BX1 |  | BC-05 | CANON i250/i255/i350/i355/i320/i450/i455/i470D/i475D CANON PIXMA iP1500/iP2000/iP1000 |
| MI-1105A-BX1 |  | BCI-3eC BCI-5C BCI-6C | CANON BJC-300J/3000/3010/3100/6000/6100/6200/6500/8200 CANON BJ F300/F600/F850/F860/F870 |
| MI-1106A-BX1 |  | BCI-3eM BCI-5M BCI-6M | CANON S400/S400SP/S450/S500/S520/S530/S530D/S600/S630/ S750/S800/S820/S820D/S830D/S900/S4500/S6300/S9000 CANON i550/i560/i850/i860/i865/i900D/i905D/i950/i960/i965/ i6100/i6500/i9100/i9900/i9900/i9950 |
| MI-1107A-BX1 |  | BCI-3eY BCI-5Y BCI-6Y | CANON MultiPASS MP700/MP730 CANON PIXMA iP3000/iP4000/iP5000/iP6000D/ iP8500/MP750/MP780 |
| MI-1108A-BX1 |  | BCI-3ePC BCI-5PC BCI-6PC | CANON BJC-300J/3000/3010/3100/6000/6100/6200/6500/8200 CANON BJ F300/F600/F850/F860/F870 |
| MI-1109A-BX1 |  | BCI-3ePM BCI-5PM BCI-6PM | CANON S400/S400SP/S450/S800/S820/S820D/S830D/ S900/S4500/S9000 CANON i900D/i905D/i950/i960/i965/i9100/i9900/i9900/i9950 CANON PIXMA iP6000D/iP8500 |

MAXINK INK REFILL KITS SERIES FOR HP & LEXMARK CARTRIDGE REFILL MODEL

| MODEL | COLOR | FOR USE ON | FOR USE ON |
|--------------|---|------------|--|
| MI-2101A-BX1 |  | 51626A | HP Deskjet Plus/310/320/340/340CBI/340CM/340CV/400/420/420C/450C/500/500C/500J/505C/505K/505J/520/540/550C/560C/560J/600/610C/630C/640C/656C/660C/670C/690C/692C/694C/695C/710C/720C/810C/812C/815C/820CXI/825CVR/830C/840C/841C/845C/850C/870CXI/880C/890C/895CXI/920C/930C/940C/948C/950C/955C/970CXI/990CXI/1000CXI/1100C/1120C/1125C/1220C/1220PS/1600C/1600CM/6122/6127/3320/3420/3425/3450/3520/3520v/3550/3650/5150/5150w/5550/5650/5650w/5850/5850w/9300/9650/5652/9670/3538/3558/3658/3668/5168/3740/3745/3840/3845/3845XJ/9680 DeskJet Portable HP DeskWriter C/CK/310/320/520/540/550C/560C/600/660C/694C HP DesignJet 200/220/600/700/750C/755CM HP OfficeJet g55/g85/g95/k80/r45/r65/r45/r65/v40/v40xi/590/630/635/710/725/LX/300/330/350 HP Fax 800 HP Color Copier 170/290 HP OfficeJet Pro 1150C/1170C/1175C HP PhotoSmart P1000/P1100/P1215/P1218/7150/7350/7550/7660/7960/7268 HP PSC 1210/2110/2175/2210/1218 APOLLO P-1200/2100/2200 Series |
| | | 51633A/M | |
| | | 51629A | |
| | | 51645A/G | |
| | | C6614D | |
| | | C6615A/D | |
| MI-2102A-BX1 |  | 51625A | HP DeskJet 200/200CC/310/320/340/350CBI/400/400L/420C/450C/500C/505J/540/550C/560J/600/610C/630C/640C/656C/660C/670C/690C/692C/694C/695C/695CC/710C/712C/720C/722C/810C/812C/830C/832C/880C/890C/895CXI/920/930C/932C/935C/940C/948C/950C/955C/960/970/990/1000/1120C/1125C/1220C/3320/3420/3425/3450/3520/3520v/3550/3650/3820/5150/5150w/5550/5650/5650w/5850/5850w/6122/6127/9300/9650/5652/1180c/9670/3538/3558/3658/3668/5168 HP DeskWriter C/CK/310/320/540/550C/560C/600/660C/694C HP OfficeJet g65/g85/g95/k60/r40/r60/r80/r45/r65/v40/590/630/635/710/775 HP OfficeJet Pro 1170C/1175C HP Color Copier 170/180/190/280/290 HP PhotoSmart 100/130/230/P1000/P1100/P1115/P1215/P1218/1315/7150/7350/7550/7660/7960/245/148/7268 HP PSC 500/750/1210/2110/2175/2210/1218 APOLLO P-2100/2200 Series |
| | | 51649A/G | |
| | | C1823D/G | |
| MI-2103A-BX1 |  | C6578A/D/G | HP DeskWriter C/CK/310/320/540/550C/560C/600/660C/694C HP OfficeJet g65/g85/g95/k60/r40/r60/r80/r45/r65/v40/590/630/635/710/775 HP OfficeJet Pro 1170C/1175C HP Color Copier 170/180/190/280/290 HP PhotoSmart 100/130/230/P1000/P1100/P1115/P1215/P1218/1315/7150/7350/7550/7660/7960/245/148/7268 HP PSC 500/750/1210/2110/2175/2210/1218 APOLLO P-2100/2200 Series |
| MI-2104A-BX1 |  | C8728A | |
| C6657A | | | |
| | | C8817A | |
| MODEL | COLOR | FOR USE ON | FOR USE ON |
| MI-3101A-BX1 |  | 12A1970 | Lexmark 1000/1020/1100/2030/2050/2055/3000/3200/5000/5700/5770/7000/7200/Z11/Z12/Z22/Z31/Z32/Z42/Z43/Z51/Z52/Z53/Z54/Z82/X63/X73/X83/X85/X125/X4250/X4270/Z705/Z715/P708/P707/P3150 Lexmark Optra Color 40/40n/45/45se Lexmark WinWriter 100 , Kodak PM100 Compaq A900/A1000/IJ300/IJ700/IJ750/IJ900/IJ1200/IJ600Series Samsung SF3000/3100/3150/4000/4100/4200/4500/4700 series Msys 4700/4800 Series, MJ4500c, SCX1000 Legend 5200MFC/z32/z33/z51 LENOVO 1201i/2401i/3110/4800i |
| | | 12A1975 | |
| | | 12A1145 | |
| | | 17G0050 | |
| | | 1361400 | |
| | | 1380620 | |
| LC6001 | | | |
| MI-3102A-BX1 |  | 12A1980 | Lexmark 3200/5000/5700/5770/7000/7200/Z11/Z12/Z13/Z22/Z23/Z25/Z31/Z32/Z33/Z35/Z42/Z43/Z45/Z45se/Z51/Z52/Z53/Z54/Z82/Z513/Z515/Z601/Z605/Z615/X73/X75/X83/X85/X63/X125/X1130/X1150/X1180/X1185/X2250/P122 Lexmark Optra Color 40/40n/45/45se, Kodak PM100 Compaq IJ300/IJ600/IJ700/IJ750/IJ900/A900/C3-1000 Samsung SF3100/4100/4200/4500 Series; Msys 4700/4800; MJ4500C LENOVO 1201i/2401i/3110/4800i |
| MI-3103A-BX1 |  | 17G0060 | |
| MI-3104A-BX1 |  | 15M0120 | |
| | | 10N0026 | |